

# Fudge Cooker/Mixer- Steam Cleaning Instructions

The instructional content provided is for general informational purposes only. It is to be used as a reference and is not to be considered a complete or exhaustive resource. Users should always consult the appropriate product manual for specific step-by-step instructions. If you are in need of further assistance, please contact Gold Medal directly at 800-543-0862 or email [info@gmpopcorn.com](mailto:info@gmpopcorn.com).

Follow the procedures below to steam the kettle every 3-4 batches during regular operation and before the machine is turned off for the day. The kettle must also be steamed out after making single batches, if the machine is turned off between batches, or if changing flavors.

**TOTAL CLEANING TIME:** Approximately 20 Minutes



1 After all product has been removed, with the machine OFF, use spatula to scrape as much access dried fudge as possible from inside the kettle and around the paddle.



2 Carefully pour in enough water to fill the kettle to right below the drum seal. This should be approximately 1.75 gallons. The water should be warm-not cold to avoid damage to the kettle.



3 Turn Heat/Motor Switch ON and ensure toggle switch is in the CLEAN position; the preset set point temperature is 230F.



4 Put the lid on the kettle and let the machine run for approximately 20 minutes; the kettle will steam and wash the residue into the water, then turn the Heat/Moto Switch OFF.

**CAUTION: Beware of rising steam.**



5 Allow unit to cool, then remove lid and carefully pour dirty water into a bucket, discard appropriately, then wipe inside of kettle with a clean cloth or paper towel to finish cleaning. For extremely dirty kettles, we recommend running a 2nd cycle.



**GOLD MEDAL®**  
Snacks, Smiles & Success!®



800-543-0862 | [gmpopcorn.com](http://gmpopcorn.com)